# Medalist® MD-225

### Thermoplastic Vulcanizate

**Teknor Apex Company** 

#### Message:

This compound is designed for medical and healthcare applications requiring oil resistance.

General Information			
Uses	Drug		
	Medical/nursing supplies		
Agency Ratings	ISO 10993 Part 5		
Appearance	Translucent		
Forms	Particle		
Processing Method	Injection molding		
Physical	Nominal Value	Unit	Test Method
Specific Gravity	0.938	g/cm³	ASTM D792
Melt Mass-Flow Rate (MFR) (230°C/2.1	6		
kg)	18	g/10 min	ASTM D1238
Molding Shrinkage			ASTM D955
Flow	2.3	%	ASTM D955
Transverse flow	2.1	%	ASTM D955
Hardness	Nominal Value	Unit	Test Method
Durometer Hardness (Shore A)	64		ASTM D2240
Elastomers	Nominal Value	Unit	Test Method
Tensile Stress			ASTM D412
100% strain	3.03	MPa	ASTM D412
200% strain	4.07	MPa	ASTM D412
Tensile Strength (Break)	4.83	MPa	ASTM D412
Tensile Elongation (Break)	280	%	ASTM D412
Tear Strength	17.5	kN/m	ASTM D624
Compression Set (23°C, 22 hr)	24	%	ASTM D395
njection	Nominal Value	Unit	
Rear Temperature	138 - 160	°C	
Middle Temperature	160 - 182	°C	
Front Temperature	171 - 193	°C	
Nozzle Temperature	193 - 216	°C	
Processing (Melt) Temp	193 - 216	°C	
Mold Temperature	21.1 - 37.8	°C	
Injection Pressure	1.38 - 5.52	MPa	
Back Pressure	0.172 - 0.689	MPa	

Screw Speed	50 - 100	rpm	
Cushion	3.81 - 25.4	mm	

Injection instructions

Drying is not necessary. However, if moisture is a problem, dry the pellets for 2 to 4 hours at 150°F (65°C).

The information and data on this page are provided by manufacturers and document providers. SHANGHAI SUSHENG assumes no legal liability. It is strongly recommended to verify all technical data with material suppliers before final material selection. All rights belong to the original authors. If any infringement occurs, please contact us immediately.

#### Recommended distributors for this material

## Susheng Import & Export Trading Co.,Ltd.

Tel: +86 21 5895 8519

Phone: +86 13424755533 Email: sales@su-jiao.com

No. 215, Lianhe North Road, Fengxian District, Shanghai, China

