# Boda BDF401HP

#### Fluoroelastomer

Chenguang Fluoro & Silicone Elastomers Co., Ltd.

### Message:

BDF401HP is a medium viscosity curative incorporated fluoroelastomer copolymer.

This grade is well suited for application where good rheological properties and excellent compression set resistance are required. BDF401HP can be compounded to meet the major fluoroelastomer specifications.

BDF401HP can be used for compression molding of O-rings and gaskets or extrusion of profiles. It can be mixed using typical fluoroelastomer compounding ingredients. Mixing can be accomplished with two-roll mills or internal mixers. Finished goods can be produced by a variety of rubber processing methods.

General Information	
Features	Low compressive deformability
	Copolymer
	Medium viscosity
Uses	Washer
	Composite
	Profile
Appearance	White
Processing Method	Composite
	Extrusion
	Profile extrusion molding
	Compression molding

Physical	Nominal Value	Unit	Test Method
Specific Gravity	1.80	g/cm³	
Mooney Viscosity (ML 1+10, 121°C)	42	MU	
Fluorine Content	66	%	
Solubility	LMW Ketones and esters		
MH <sup>1</sup> (177°C)	2.65	N·m	
ML <sup>2</sup> (177°C)	0.320	N·m	
t'90 <sup>3</sup> (177°C)	2.4	min	
ts2 <sup>4</sup> (177°C)	1.2	min	
Hardness	Nominal Value	Unit	Test Method
Durometer Hardness <sup>5</sup> (Shore A)	76		ASTM D2240
Elastomers	Nominal Value	Unit	Test Method
Tensile Strength <sup>6</sup> (Yield)	15.0	MPa	ASTM D412
Tensile Elongation <sup>7</sup> (Break)	200	%	ASTM D412
Compression Set (200°C, 70 hr)	16	%	ASTM D395B
Additional Information			

Test Compound: Polymer: 100

MT Black (N990): 30 phr

MgO: 3 phr Ca(OH)2: 6 phr Curing Condition: Press: 10 min at 170°C Oven: 24 hr at 230°C

NOTE	
	MDR2000 Rheometer, 100cpm,
1.	0.5° Arc, 6 minutes
	MDR2000 Rheometer, 100cpm,
2.	0.5° Arc, 6 minutes
	MDR2000 Rheometer, 100cpm,
3.	0.5° Arc, 6 minutes
	MDR2000 Rheometer, 100cpm,
4.	0.5° Arc, 6 minutes
	Press Time: 10 min, Press
	Temperature: 170°C, Post Cure
	Time: 24 hr, Post Cure
5.	Temperature: 230°C
	Press Time: 10 min, Press
	Temperature: 170°C, Post Cure
	Time: 24 hr, Post Cure
6.	Temperature: 230°C
	Press Time: 10 min, Press
	Temperature: 170°C, Post Cure
	Time: 24 hr, Post Cure
7.	Temperature: 230°C

The information and data on this page are provided by manufacturers and document providers. SHANGHAI SUSHENG assumes no legal liability. It is strongly recommended to verify all technical data with material suppliers before final material selection. All rights belong to the original authors. If any infringement occurs, please contact us immediately.

### Recommended distributors for this material

## Susheng Import & Export Trading Co.,Ltd.

Tel: +86 21 5895 8519

Phone: +86 13424755533 Email: sales@su-jiao.com

No. 215, Lianhe North Road, Fengxian District, Shanghai, China

