

RheTech Polypropylene RCC220-01

Polypropylene Copolymer

RheTech, Inc.

Message:

20% Calcium Carbonate Reinforced, Recycled Content, Polypropylene Copolymer, Black.

General Information			
Filler / Reinforcement	Calcium carbonate filler, 20% filler by weight		
Recycled Content	Yes		
Features	Copolymer		
Appearance	Black		
Processing Method	Injection molding		
Physical	Nominal Value	Unit	Test Method
Specific Gravity	1.07	g/cm ³	ASTM D792
Melt Mass-Flow Rate (MFR) (230°C/2.16 kg)	18	g/10 min	ASTM D1238
Hardness	Nominal Value	Unit	Test Method
Durometer Hardness (Shore D)	71		ASTM D2240
Mechanical	Nominal Value	Unit	Test Method
Tensile Strength	22.1	MPa	ASTM D638
Flexural Modulus	1450	MPa	ASTM D790
Impact	Nominal Value	Unit	Test Method
Notched Izod Impact	53	J/m	ASTM D256
Dart Drop Impact	11.5	J	ASTM D5420
Thermal	Nominal Value	Unit	Test Method
Deflection Temperature Under Load			ASTM D648
0.45 MPa, not annealed	88.9	°C	ASTM D648
1.8 MPa, not annealed	54.4	°C	ASTM D648
Injection	Nominal Value	Unit	
Drying Temperature	65.6 - 82.2	°C	
Drying Time	1.0 - 2.0	hr	
Suggested Max Moisture	0.050	%	
Rear Temperature	199 - 227	°C	
Middle Temperature	204 - 232	°C	
Front Temperature	210 - 238	°C	
Nozzle Temperature	216 - 227	°C	
Mold Temperature	26.7 - 48.9	°C	
Injection Pressure	2.76 - 10.3	MPa	
Holding Pressure	2.07 - 8.27	MPa	
Back Pressure	0.345 - 1.03	MPa	

Injection instructions

Injection Speed: Variable - Application DependantScrew RPM: Recovery 3 seconds before mold opensCycle Time: Wall Thickness Dependant

The information and data on this page are provided by manufacturers and document providers. SHANGHAI SUSHENG assumes no legal liability. It is strongly recommended to verify all technical data with material suppliers before final material selection.All rights belong to the original authors. If any infringement occurs, please contact us immediately.

Recommended distributors for this material

Susheng Import & Export Trading Co.,Ltd.

Tel: +86 21 5895 8519

Phone: +86 13424755533

Email: sales@su-jiao.com

No. 215, Lianhe North Road, Fengxian District, Shanghai, China

